

















Velikosti knoflíku - Buttons sizes

line	14"	16"	18"	20"	22"
					
mm	8,9	10,2	11,4	12,7	14,0

line	24"	26"	28"	30"
				
mm	15,2	16,5	17,8	19,1

line	32"	36"	40"	44"
				
mm	20,3	22,9	25,4	28,0

line	48"	54"	60"
			
mm	30,5	34,3	38,1
